

# [Smart Watch]

#### [Schematic Diagram of the Whole Machine]



Mill: Horn 心率: Heart Rate 表带: Strap

显示層: Display Screen 开关键, Power Button:



## [Schematic Diagram of Dial Switching]

1. Dial interface: Choice of four dial modes, long press for 3 seconds, swipe left and right to choose the mode











#### [ Adaptive Platforms and Requirements ] 1. Android 4.4 and above.

- 2. IOS8.5 and above.
- The hardware of phone supports Bluetooth 4.0.
- [ Function Introduction of Smart Watch ]

measurement data

1.UI switching function: dial interface stroke up to enter (short message) stroke down (dial) stroke left to enter menu menu stroke up (return)

- 2. Call settings: Open the setting of the phone and get into the Bluetooth to find the corresponding address of the smart watch. And you can view the phone book, call history and others on the smart watch.
- 3. Data interface: Keep track of exercise time, steps, kilometres and calories burned that day. And it can keep track of the day of deep sleep and light sleep.
  - 4. Heart rate interface: Long press on the heart rate interface of the smart watch to measure your current heart rate value, in this interface, it can display your latest 10 heart rate
- 5. Blood pressure function interface: press long on the watch blood pressure interface to measure your current blood pressure value, and your latest 10 blood pressure measurement data can be displayed on this interface.
- 6.Sport mode: Long press to enter in the sport mode interface, there are five models of walking, running, cycling, skipping rope, football. Click it and start recording exercise time and calories,
- and you can use the watch to control pause or end. 7.Message: You can check the message at any time after the Bluetooth of mobile phone being connected with the APP.
- 8. Message interface: open QQ WeChat and other reminders in the private APPlication on the app. When there are QQ, WeChat, incoming calls, SMS and other messages on the mobile phone, the watch has corresponding reminders.
- 9. Search my device: Find your mobile phone by the watch or find the watch by your mobile phone.
- Music control: When connected to a mobile phone, the watch can control the player on the phone, when the mobile phone is playing music, you can long press to enter the watch to control the

- mobile phone to play or pause the music, or change to previous song or the next song.
- or the next song.

  11.Setting: Long press on this interface to select other functions in
- the setting, includes stopwatch, brightness adjustment and off.

  12. Remote camera: Control it from the watch-take pictures with the camera on the phone; That needed to start the camera of the Android phone in advance.
- 13.Other functions: Sedentary reminder, charging reminder, upgrade reminder, caller ID, alarm clock, calculator, file management, profile recording, stopwatch, calendar, automatic language matching, etc.

[APP Connection



APP QR code

- Scan the QR code above, or search for "Fun to Wear" in the
  Android App Store, or search for "Fun to Wear" in the application
  of treasure. Choose to download and install the "Fun to Wear" App
  according to different devices. If your mobile phone is iphone, then
  go to the Apple Store and search for "Fun to Wear" directly to
  download and install the App, Scan QR code directly abroad. You can
  also download and install the app by searching "FunWear" in the
  Google store.
- Long press the QR code for 3 seconds to boot, open and enter the download interface. According to the interface instructions, select different mobile phone models to complete the download.
- Connect Bluetooth 4.0 Connection Method: Click on the mobile phone settings-click on the mobile phone Bluetooth-click on the watch Bluetooth-find the last page (about the inside) of the watch settines LE address: (e.g. C5:d3:24:2f:70:94) After checking the

address-click on the inside of mobile phone APP (Fun to Wear)-click on the device-find the Bluetooth name-click on the binding device-it will automatically connect

4. Connect Bluetooth 3.0; The first connection method: mobile phone settings-click on mobile phone bluetooth-click on watch bluetooth-mot bluetooth address on the last page (about the inside) in the watch settings, click on the second connection method, click on the watch bluetooth menu-click on the mobile phone bluetooth hame-click on the bluetooth meni-find the mobile phone bluetooth name-click on the connection-mobile phone bluetooth name-click on the connection-mobile phone bluetooth interface pairing menu-click on the authorized address book-click on the pairing-then confirm that you are connected Note: If Bluetooth 4.0 is connected first, Bluetooth 3.0 cannot be connected. You must disconnect Bluetooth 4.0 to connect Bluetooth 3.0 IOS system has firewall, Bluetooth connection, watch must be connected to mobile phone.

### APP Function Introduction

Home, Device, My Page




1. Steps: Draw a chart based on the number of steps, distances and calories burned each day when the user wears the smart watch Provide the user with the required number of steps for per day /



week / month

 Sleep: Record sleep data in graph form for per day / week / month, using the data in the smart watch and calculating the daily sleep quality and sleep duration.





4.Heart rate: Show your detail information of your heart rate for per day / week / month



 Blood pressure: display your blood pressure details every day / every week / every hour every month

#### Basic Parameters

size	1.3 inch round screen	
Bluetooth	Bluetooth4.0	
Waterproof level	Screen IP67 waterproof level	
Type of battery	Polymer lithium battery	
Battery capacity	290mAh	
Charging time	Two hours	
Watch size	Length 54.5mm*46m m*11.8m mStra circumference 275mm	
Charging mode	Charging clip, charging voltage 5V	
Touch screen	Full circle full touch	
Package	Smart Watch + Strap + Charging Clip + Product Manual	

#### WARNING

Please follow the doctor's instructions, do not selfdiagnose and treat based on this measurement result, users with blood circulation disorders and blood diseases should be treated under the guidance of a doctor, the measurement results of this product are for reference only and are not to be used as a basis for any medical purpose.

	Warranty Card			
Customer Information				
Туре		Vending Institute	(Signature)	
Customer Name		Telephone Number		
Sales Call		Date of Purchase		
SIM code				
Customer Address				
Sales Address				
	•	Summary		
Date	Sympto	Overhaul	Note	
	m			